
Legs and Bases.com

Slim Flip Assembly Instructions

Parts List:

- (1) Packet of hardware
- (1) Steel beam
- (2) Side hinges (one left and one right)
- (1) Center hinge with release mechanism
- (2) Columns for T or AT-Legs
- (2) Feet for TL or ATL Legs
- (4) Casters (optional)



1-866-266-4344: phone

www.legsandbases.com

678-456-6046: fax

Step 1: Assemble legs by setting mounting plate on the floor with the bottom of the column up. Place the foot over the column lining up the holes in the foot and the column. Insert (1) bolt through the foot and into the column. Tighten bolt securely. If you purchased casters, remove glides and install casters now.



Step 2: Slide legs into the slot on the end of beam, do not bolt legs at this time.



1-866-266-4344: phone

www.legsandbases.com

678-456-6046: fax

Step 3: Attach hinges and legs to the steel beam. Hinges sit on top of the steel beam. Use a 3/16" Alan wrench and the provided hex head bolts to attach legs and hinges to the steel beam.



Step 4: Attach the center hinge with release handle to steel beam. Use a 3/16" Alan wrench and the provided hex head bolts to attach the hinge to the steel beam.



1-866-266-4344: phone

www.legsandbases.com

678-456-6046: fax

Step 5. If you purchased a complete table (Slim Flip and Top), place top upside down on the floor. Place assembly upside down on the table top and attach base to the table top using the included wood screws. Line up hinges with the predrilled holes in the under side of the table top.



Enjoy your table!



www.legsandbases.com